




ELITE



- 1) Grasp the lower "V" at the centre. Lift and pull frame half way out, or if top already on frame go to 4




- 2) Place fabric top on frame work. Attach to each corner.



- 3) Attach Velcro to each corner, then pull frame completely out.




- 4) Push plastic socket over button on leg to tension roof.




- 5) Lift each leg until the button snaps into the first hole.



- 6) If the roof has a sag, use the hand crank in the center of the frame to raise the center adjustment.



- 7) For height adjustment push leg buttons and slide up to any of the (5) holes.



- 8) Push lower buttons to drop canopy to lower level. Push in roof tensioning buttons. Push frame inwards. **DO NOT FORCE.**

- 9) The top may be left on the frame. To do so pull the fabric up from the centre of the frame completely. This prevents the fabric from being caught in, and cut, by the scissor bars.